



# Toote registreerimise juhend


1. Ava oma interneti lehitseja ja mine aadressile [my.garmin.com](https://my.garmin.com) ning loo endale konto, klikates „[Create new account](#)“ nupul. Kui sul on juba konto olemas liigu punkti 4.




2. Sisesta lahtritesse andmed ning liigu edasi vajutades „Next“ nupule.




3. Siin saad valida tooteid, mille kohta hakatakse saatma teateid e-mailile. Kui sa ei soovi teateid saada, vali „Do not subscribe“.




4. Tote registreerimiseks vali „[Register now](#)“.




5. Valige „Garmin Device or Accessory“ ning klikake „Next“ nupul.




6. Sisestage seadme seeria number (8-9 kohaline tähe ja numbri kombinatsioon; asub seadme korpusel.) ja klikake „Next“.




7. Kui arvutisse ei ole eelnevalt installeeritud Garmin Communicator Plugin, siis klika „Download“ nupul. Kui Garmin Communicator plugin on installeeritud liigu edasi punktini 13.



8. Avanenud aknas klika „Download for Windows“ nupule. Mac arvutile leiad allalaetava faili paremast tulbast.




9. Pärast allalaadimist ava Garmin Communicator Plugin ja vajuta Next nupule.




10. Sulge kõik veebilehitsejad ning vajuta „Next“ nupule.




11. Kui installeerimine on lõpetatud, ühenda oma GPS arvutiga ning vajuta „Done“ nupule, misjärel kuvatakse programmi test lehekülg.




12. Kui programm on õigesti paigaldatud, kuvatakse lehel arvutiga ühendatud Garmin GPS seadme nimetus ja id number. Klika myGarmin ikoonil ning logi sisse.




13. Kui seade on ühendatud arvutiga, kuvatakse üleval kiri mudeli numbrist ja tarkvara versioonist (kui te oma seadet seal ei näe, vajutage „Find Devices“ nuppu). Edasi liikumiseks vajutage „Next“ nuppu (kui nupp „Next“ ei ole aktiivne, vajutage Download to Device“ nuppu).




14. Kui „Next“ nupp ei olnud aktiivne ja vajutaside „Download to Device“ nuppu, laetakse GPS seadmesse tarkvara uuendus.



15. Kui tarkvara uuendus on laetud, ühenda seade arvuti tagant lahti ja luba seadmel taaskäivituda. Kui näed seadme ekraanil esilehte, lülita seade välja ja ühenda uuesti arvutiga. Vajuta „Find Device“.



16. Pärast otsimist kuvatakse arvutiga ühendatud seade, seadme id ja tarkvara versiooni number. Liigu edasi vajutades „Next“ nupule.



17. Sisesta lahtritesse oma andmed. \*-ga tähistatud väljad on kohustuslikud. „State/Province“ pole kohustuslik. Andmed sisestatud, liigu edasi vajutades „Next nupul“.

The screenshot shows the myGarmin registration page in Internet Explorer. The browser address bar shows the URL: <https://my.garmin.com/mygarmin/registration/scanDevice.faces>. The page header includes the GARMIN logo and navigation links: Company | Products | Solutions | Extras | Maps | Support | Shop | myGarmin. Below the header, there is a breadcrumb trail: Home > Product Registration and a welcome message with links for myAccount, myOrders, mySupport, and Sign Out.

### Product Registration

Enter your contact information.  
\* Indicates a required field.

*Full Name	Email	*Address
<input type="text"/>	<input type="text"/>	<input type="text"/>
Address 2	*City	*State/Province
<input type="text"/>	<input type="text"/>	none
*Zip/Postal Code	*Country	
<input type="text"/>	Estonia	
Phone Number		
<input type="text"/>		

Buttons:

#### Why Register?

**Protect Yourself.** When you register your product, you can verify your ownership for insurance purposes if your product is ever lost or stolen (in the event you have insurance coverage on your product). Registering also allows us to contact you in the unlikely event that a safety modification or warning is issued for your product.

**Get Updates.** Registering your product gives you the option to find out about product enhancements, promotional material, and software and product upgrades.

**Customize Your Account.** The information you enter during the registration process is stored in...

18. Toode on registreeritud. Kui Teil on õigus saada tasuta kaardi uuendust, liikuge edasi järgmisele lehele „Next“ nupu abil.

The screenshot shows the myGarmin Free Map Update page in Internet Explorer. The browser address bar shows the URL: <https://my.garmin.com/mygarmin/map/updates/freeMapUpdate+Home.faces>. The page header is identical to the previous screenshot.

### Free Map Update

Thank you for registering your product.

Our records indicate that you are eligible for a free map update for the device below. Follow the screen prompts to take advantage of this special offer today.

Unit: nüvi® 250  
Serial Number:   
Map Update: City Navigator® Europe NT 2009 Map Update  
Expiration: Free update expires Dec 27, 2008 \*


\*You have 61 days to take advantage of this free map update. After 61 days, this map update will be available for purchase from our online store.

Customers outside the US and EU will be responsible for any additional taxes and customs fees.


Buttons:

Copyright © 1995-2008 Garmin Ltd. or its subsidiaries | [Privacy Statement](#) | [Terms of Use](#) | [Site Map](#)


19. Pead tegema valiku, kas soovid uuendust alla laadida (Download) või saada postiga DVD plaadil (Disk). Edasi liikumiseks vajuta „Next“ nuppu.  
Postiga saatmisel lisandub postikulu 6.75 EUR + maksud. Allalaadimine on tasuta. Juhend jätkub „Download“ valiku tegemisel.



20. Kopeeri arvutisse või kirjuta üles 8 tähe ja numbri kombinatsioon Product Key. Vali sobiv allalaadimis fail (Windows arvutitele „PC Download“).




21. Avanevad aknas soovitage paigaldada Garmini Download Manager klikates lehe ülaosas ning valida „Install ActiveX Control“.




22. Avanenud aknas saate paigaldada Garmini allalaadimisabi vajutades „Install“.




23. Pärast paigaldamist valige arvutis kaust, kuhu soovite faili salvestada ning vajutage „Save“.



24. Kaardifaili laetakse alla.




25. Kui fail on alla laetud, vajuta kaardi paigaldamiseks „Launch“ nuppu.



26. Järgi ekraanil antavaid juhiseid. Edasi liikumiseks vajuta „Next“ nuppu.



27. Programm paigaldab vajadusel vajalikud draiverid.  
Jätkamiseks vajuta „Next“.




28. Klika märkeruudus ja vajuta „Next“.



29. Programm vaatab, kas GPS`il on kõige uuem tarkvara ja vajadusel uuendab seda.



30. Kui tarkvara uuendus on laetud, ühenda seade arvuti tagant lahti ja luba seadmel taaskäivituda. Kui näed seadme ekraanil esilehte, lülita seade välja ja ühenda uuesti arvutiga. Oota, kuni arvuti tuvastab seadme ja vajuta „Next“.



31. Sisesta „Product key“, mille leiad registreerimise kinnitusest (saadetud e-mailile) või logides sisse myGarmin.com`i.

The screenshot shows the Garmin Map Update interface. At the top left is the GARMIN logo, and at the top right is the text "Map Update". Below the logo, there is a prompt: "Please enter your Product Key:" followed by a text input field. Underneath, it asks "Not sure where to find your Product Key?" and provides instructions: "The Product Key is included in your Order Confirmation email and also in your myGarmin account at http://my.garmin.com." and "After logging into myGarmin, click on myMaps then Map Downloads." To the right, there is a "Map Downloads" section with a "SAMPLE" watermark. It contains instructions about installing a download manager and lists download links for "Map Update 2008 City Navigator North America NT Download", "PC Download", "Mac Download", and "Product Key: ZABCDEF3". Below this, it shows "Download Expiration Date: Sep 16, 2008". At the bottom of the interface are "Install" and "Exit" buttons. A copyright notice "©2008 Garmin Ltd. or its subsidiaries" is at the very bottom.

32. Kui su seadmel pole piisavalt mälu, saad seadmesse paigaldada vaid ühe regiooni. Vali region ja „Install“.

The screenshot shows the Garmin Map Update interface with a dropdown menu open. At the top left is the GARMIN logo, and at the top right is the text "Map Update". Below the logo, there is a message: "Since our map data gets larger and more detailed each year, the full coverage map requires more memory than what is available on your device. Please select one of the regions below to install to your device." Below this message is a dropdown menu with the following options: Italy & Greece, Alps, DACH & CZ, UK & Ireland, France, Spain & Portugal, Nordics, BeNeLux, Northwest Eastern Europe, BeNeLux & France, and Germany. At the bottom of the interface are "Install" and "Exit" buttons. A copyright notice "©2008 Garmin Ltd. or its subsidiaries" is at the very bottom.


33. Kaardid paigaldatakse esmalt arvutisse. Kui su seadmesse ei mahu kõik kaardid, saad hiljem MapSource programmi kaudu laadida ülejäänud kaardid mälukaartile ja lisada mälukaart seadmesse.



34. Seejärel laetakse kaardid seadmesse.



35. Kui kaardid on seadmesse laetud, ühendage seade arvuti tagant lahti ja võite hakata GPSi kasutama.



Kaardi uuendus võib kustutada seadmest eestikeelse hääljuhenduse. Tagasi peale saate selle [WebUpdater](#) tarkvara abil. [www.garmin.ee](http://www.garmin.ee)->Tugi->Allalaadimine->WebUpdater tarkvara.